

How-To: Reduce smoke collector speed to prevent jigs from moving

The lighter foam jigs may blow away during engraving. To prevent this, turn down the vacuum speed with the adjustment knob.



Turn the knob completely counter-clockwise (minimum).
When you're done, restore the knob setting to its original position.