

Scan these codes from top to bottom to setup scanner

**Enter/Exit Configuration Mode**



~ **Configurable Prefix Character #1**  
can be added and assigned for data



**Code Byte 1**



**Code Byte 7**



**Code Byte 5**



~ **Configurable Prefix Character #2**  
second configurable prefix character



**Code Byte 1**



**Code Byte 1**



**Code Byte 1**

**Enter/Exit Configuration Mode**



**Recall Defaults**

